



YAMAHA EC-05 外送架 INSTALLING MANUAL FOR DELIVERY RACK FOR EC-05

▋▋安裝說明書


- 感謝您購買 **M**工 產品,在此向您至上萬分謝意。使用之前,請您務必詳讀並參照安裝説明,並且正確組裝。
- Before installing, please read Installing Manual well.

■■ 1-1 配件 ACCESSORIES:





■■ 2-1 安裝說明示意圖 Installing Manual



- 1.將NCY外送架和貨架後扶手對應螺絲孔依個人適合的 位置,鎖緊4顆附贈的專用螺絲和螺母/墊片。
- 1.Please choose the bolt hole of REAR RACK & DELIVERY RACK for the available position by the personal requirement, lock 4pcs for each bolt, nut and spacer tightly.

- 注意!專用螺絲必須確定鎖緊,防止機車行駛中 晃動鬆脫產生危險。
- 2. Attention! Please lock bolts tightly to prevent from the danger of the bolts getting loose as scooter riding.

本產品荷重限制6kgs/ Max loading 6kgs

- ※本商品主要作為載物用途,移車、架車時,請勿作為 抓握的施力點,以免損壞商品本體或車體。
- **DELIVERY RACK is only for products carrying using.
 Please prevent from holding DELIVERY RACK to move scooter or make the main stand to damage DELIVERY RACK or scooter.

